

Address Marker Plaque Installation Instructions

1. Measure the distance between the centers of the keyhole slots on the back of the plaque.
2. Select location on the wall and using the measurement from step 1, mark the location for the keyhole slots. Important – after marking the wall, verify your markings with the distance between the slots on the plaque.
3. After verifying alignment and spacing, you are ready to drill the pilot holes for mounting. Follow instruction “A” for wood siding. Follow instruction “B” for brick or masonry.

Instruction A (wood siding): Drill pilot hole with 3/32” drill bit. Screw mounting screws into the wall, leaving approximately ¼” gap between the wall surface and screw heads.

Instruction B (brick/masonry): Drill 3/16” hole 1” deep and insert plastic screw sleeve (provided). Insert screws leaving approximately ¼” gap between the wall surface and screw heads. Note: for applications where the brick mortar is significantly recessed, use longer screws.

4. Mount plaque on wall.