

Detail of Trimless Fire Extinguisher Cabinets

TRIMLESS CABINETS FOR NON RATED WALLS - INSTALL OVER DRYWALL OR UNDER PLASTER

FLANGE FOR DRYWALL WITH DRYWALL BEAD 1034WBV10

FLANGE FOR 3/4" PLASTER WITH PLASTER STOP 1034PWW10

TRIMLESS CABINETS FOR FIRE-RATED WALLS - INSTALL BETWEEN LAYERS OF DRYWALL OR PLASTER

FLANGE FOR PLASTER RECESSED 3/4" FROM CABINET FACE - INSTALL 1ST LAYER OF SUBSTRATE, THEN CABINET, THEN APPLY METAL LATH AND PLASTER 1034HV10

FLANGE FOR 5/8" DRYWALL RECESSED 5/8" FROM CABINET FACE - INSTALL 1ST LAYER OF DRYWALL, THEN CABINET, THEN FINAL LAYER OF DRYWALL 1034DV10

