




Access Doors - 08.31.00

Overview:

Access Door products are designed and built for years of convenient access to equipment. The following are general instructions for installing, operating and maintaining access door products. These are recommended general guidelines only. Locally accepted installation practices and procedures should be followed when applicable.

Installation:

- 1. Finished door frame opening is to be $\frac{1}{4}$ " (6mm) larger than the door frame for each dimension of the door (width + $\frac{1}{4}$ " (6mm), height + $\frac{1}{4}$ " (6mm)).
- 2. The door must be installed square with the door frame.
- 3. Do not twist or distort the door frame in any direction.
- 4. Fasten hinge side first, tight to the framing.
- 5. The door frame is to be fastened directly and securely to the wall or ceiling framing through all the holes provided in the frame. Screws shall penetrate ½" into steel studs and 1" into wood studs.



Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-5545
info@ameraproducts.com