


#### **INSTALLATION INSTRUCTIONS**

# POWDER COATED AND STAINLESS STEEL PARTITIONS



Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-5543
info@ameraproducts.com



#### Thank you for choosing ASI Accurate Partitions

This installation guide was designed to cover as many variations of hardware and mounting styles as possible, while also trying to keep it light and focused.

While all materials and standard mounting selections are present, in order to cover the numerous choices of hardware, we have presented each material with it's default hardware. Therefore, while each type is covered, it will be with it's most common mounting style (i.e. continuous brackets on ceiling-hung, piano hinges on Solid Plastic (HDPE), etc).

Please read all steps in their entirety before beginning actual install, as some field conditions and hardware combinations may require alternate installation.

Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 849-3542
info@ameraproducts.com



#### Table of Contents

<u>Floor Anchored/Overhead Braced</u>	<u>Page</u>
Step 1,2,3	1
Step 3,4,5	2
Panel to Pilaster/Wall Two Ear Assembly	3
Panel to Pilaster/Wall One Ear Assembly	4
Pilaster/Wall One Ear Assembly	5
Pilaster/Panel Alcove Assembly	6
Pilaster/Panel Inline Assembly	7
Door Hardware Assembly (Typical All Styles)	8A-8B
Headrail Assembly	9
Urinal Screen Assembly	10
Floor Anchored	
Step 1,2,3	11
Step 3,4,5	12
Panel to Pilaster/Wall Two Ear Assembly	13
Panel to Pilaster/Wall One Ear Assembly	14
Pilaster/Wall One Ear Assembly	15
Pilaster/Panel Alcove Assembly	16
<u>Ceiling Anchored</u>	
Step 1,2,3	17
Step 3,4,5	18
Panel to Pilaster/Wall Two Ear Assembly	19
Panel to Pilaster/Wall One Ear Assembly	20
Pilaster/Wall One Ear Assembly	21
Pilaster/Panel Alcove Assembly	22

Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
rax: (407) 840-3543
info@ameraproducts.com



#### **Table of Contents**

<u>Floor Anchored and Ceiling Anchored</u>	<u>age</u>
Step 1,2,3	23
Step 3,4,5	24
Panel to Pilaster/Wall Two Ear Assembly	25
Panel to Pilaster/Wall One Ear Assembly	26
Pilaster/Wall One Ear Assembly	27
Pilaster/Panel Alcove Assembly	28
Pilaster/Panel Inline Assembly	29
<u>Full Height Bracket Kits</u>	
Panel to Pilaster/Wall Two Ear Assembly	30
Panel to Pilaster/Wall One Ear Assembly	31
Pilaster/Wall One Ear Assembly	32
Urinal Screen Assembly	33
<u>Product Information</u>	
Care and Maintenance of Toilet Partitions	34

The Components for this project have been custom fabricated. They are guranteed with respect to manufacture and workmanship and were inspected at the factory.

Before beginning work, the units should be inspected. If damage occurred in transit, report immedicately to the freight company or other agencies that may have caused the damage.

Distributed by www.AmeraProducts.com Phone: (800) 608-6548 Fax: (409) 840-5542 info@ameraproducts.com

FIGURE 1

FIGURE 3



#### STEP 1 FLOOR ANCHORED/OVERHEAD BRACED


- A. Review the layout drawings and package lists that have accompanied this job.
- B. Before proceeding, confirm that backing of walls and floor is adequate to support secure mounting of the toilet compartment units.
- C. Establish and mark pilaster center line from back wall.
- D. Establish and mark panel center lines for wall brackets.
- E. Establish pilaster floor fastener locations from side wall according to shop drawings. (Note floor fasteners are located 1" from lockstrip edge of pilaster.)
- F. Mark wall bracket holes using the brackets as templates.

#### STEP 2 WALL BRACKETS AND FLOOR BRACKETS

- A. Drill holes for wall brackets and floor fastenings of appropriate size for particular fastening devices supplied.
- B. Insert anchoring devices in walls and secure wall brackets.
- C. Insert expansion shields or other floor fastening devices. position shoe clips and "L" brackets over expansion shields and secure loosely with screws.


# FIGURE 2

ፍ



#### STEP 3 POSITION PANEL

- A. Place panel on a support, 12" above the floor.
- B. Set it into wall brackets,but do not fasten panel at this time.




Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-3542
info@ameraproducts.com



## STEP 4 PILASTER PREPARATION


- A. Align U-brackets in position on rear of pilasters.Refer to layout drawings and make sure brackets are in alignment with wall brackets.
- B. Fasten U-brackets to pilaster with sheet metal screws.
- NOTE: Pilasters at wall do not require U-brackets, but should be prepared for wall (and floor fastening) as required by compartment layout. If floor fastening is omitted, three wall brackets should be used.



#### STEP 5 INSTALL PILASTERS

- A. Insert the leveling bolt into the threaded mounting foot at the bottom of the pilaster.
- B. Insert the pilaster into the shoe.
- Level the top of all pilasters by adjusting the leveling bolt to desired position.
- Note: To determine how far to insert the leveling bolt, find the highest point on the floor, and fully insert the bolt on the pilaster that will be mounted in that location. Adjust all other leveling bolts accordingly.

FIGURE 5



MOUNTING DETAIL

# STEP 6 SECURING PILASTERS/PANELS

- Plumb each pilaster and fasten the pilaster to panel using through bolts with barrel nuts or sheet metal screws.
- B. Establish door openings by setting pilaster mounting.
- C. Tighten self tapping screw to "L" brackets.
- Slide stainless steel shoe down to floor level, firmly engaging shoe clips.
- F.Remove panel support device.




FIGURE 6

Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-5542
info@ameraproducts.com



## FLOOR ANCHORED/OVERHEAD BRACED PANEL TO PILASTER/WALL


TWO EAR ASSEMBLY


Fasten pilaster to panel using sheet metal screws(Refer to steps 4 & 6 )

Pre-drill for screws with 1/8" bit.

Pilasters must be both plumb and level. To assist in leveling, headrail may be lightly positioned across adjacent pilasters(do not fasten at this time)

Remove support device.





Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-3542
info@ameraproducts.com



# FLOOR ANCHORED/ OVERHEAD BRACED PANEL TO PILASTER/WALL ONE EAR ASSEMBLY


Fasten pilaster to panel using sheet metal screws(Refer to steps 4 & 6)

Pre-drill for screws with 1/8" bit.

Pilasters must be both plumb and level. To assist in leveling, headrail may be lightly positioned across adjacent pilasters(do not fasten at this time)

Remove support device.

	Pa	nel Hardware Kit (P/N 40-8515010G) Inclu CHROME PLATED ZAMAC	des:
	Pa	nel Hardware Kit (P/N 40-8265011G) Inclu STAINLESS STEEL	des:
P/	ART ID.	DESCRIPTION	QTY
1	Щ	One Ear Bracket	(2)
2	Ш	"U" Bracket	(2)
3	-	Vandal Resistant 2 1/2" S.M.S	(4)
4		Plastic Shields	(4)
5	-	Vandal Resistant 5/8" S.M.S	(12)






#### FLOOR ANCHORED/OVERHEAD BRACED PILASTER/WALL **ASSEMBLY**


Fasten using sheet metal screws.

Pilasters must be both plumb and level. To assist in leveling, headrail may be lightly positioned across adjacent pilasters(do not fasten at this time)

Establish bottom door openings by adjusting pilaster "L" brackets (anchoring) to desired position and tightening screws.(See step 6)

	Pilaster/	Wall Hardware Kit (P/N 40-8515210G) Include CHROME PLATED ZAMAC	des:
	Pilaster/	Wall Hardware Kit (P/N 40-8265211G) Included STAINLESS STEEL	des:
Р	ART ID.	DESCRIPTION	QTY
1	Щ	One Ear Wall Bracket	(2)
2	-	Vandal Resistant 2 1/2" S.M.S	(4)
3		Plastic Shields	(4)
4	-	Vandal Resistant 5/8" S.M.S	(8)






To Fasten Pilaster To Panel.

Distributed by v.AmeraProducts.com Phone: (800) 608-6568 Fax: (409) 840-3543 info@ameraproducts.com






Note: CHROME PLATED Replace KIt#8517310 with Kit#8517320 for two ear panel locations.

Note: STAINLESS STEEL Replace Kit#8267311 with Kit#8267321 for two ear panel locations.






Distributed by www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-3542
info@ameraproducts.com



FLOOR ANCHORED/ OVERHEAD BRACED PILASTER/PANEL/PILASTER INLINE ASSEMBLY

P	ART ID.	DESCRIPTION	QTY
1	•	Alcove Clips	(12)
2	•	Vandal Resistant Step Bolts 1" Long	(12)
3	<b>%</b> □	Vandal Resistant Barrel Nut	(12)
4	-	Vandal Resistant 5/8* S.M.S	(24)




Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
rax: (409) 840-3543
info@ameraproducts.com



- A. Secure lower hinge to the pilaster with two through bolts & two barrel nuts.
- B. Secure upper hinge to pilaster with two through bolts and two barrel nuts.
- C. Insert box cam into lower door hinge portion. The short key toward the edge of the door.
- D. Lowest point of cam pintle sets door "rest" position. Rotate pintle to desired position, then tighten locking nut.
- E. Install door by placing the box cam over the hinge pintle. Position to of door over upper pilaster hinge and insert hinge pin until flush with top of door.

#### Continued on Page 8B



Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-3542
info@ameraproducts.com

PART ID

2

3

4

5

8

9

10

11

DESCRIPTION

Top Hinge

Hinge Pin

Battom Hinge

Hinge Pintle Nylon

Hinge Washer External

Hinge Washer Internal

Indicator Side Latch Outside

Indicator Slide Latch Inside

Coat Hook & Bumper

Hinge Nut 5/16"

Box cam Nylon

QTY

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(1)

(4)

(4)

(6)

(2)

(1)

(1)

(1)

(1)

(1)

(2)


(1)



- F. Insert the indicator drive pin (#19) into the back of the indicator slide latch (#9).
- G. Turn the indicator dial until the indicator window shows red.
- H. Slide the handle of the indicator slide latch (#10) so that the latch will be in the locked position.
- I. Align both halves of the indicator slide latch with the 3 predrilled holes in the door.
- J. Secure the latch with two 1" step bolts (#15).
- K. With the door closed and the latch engaged, align the keeper (#16) with the latch bar.
- L. Drill two 9/64" holes in the pilaster using the keeper as a guide.
- M. Attach the keeper to the pilaster using two 5/8" screws (#14).
- N. Place the coat hook (#11) 10" from the top of the door and centered from side to side.

<u>Note:</u> Federal ADA guidelines recommend that the coat hook be no more than 48" above the floor. If the door swings in, place the bumper so that it strikes the wall before any other part of the door.


- O. Using the coat hook (#11) as a guide, drill two 9/64" holes, and secure the coat hook with two 5/8" screws (#14).
- P. Place the inside door pull (#17) between 34" & 48" above the floor. Using the pull as a template, drill two 1/4" holes through the door.
- F. Align both halves of the door pull (#17 &#18) with the 1/4" holes and secure them with two 1-1/2" step bolts (#21).
- G. Place the outswing bumper (#20) near the bottom corner of the door on the strike side.
- O. Using the bumper as a guide, drill two 9/64" holes, and secure the bumper to the door with two 5/8" screws (#14).




PART ID.	DESCRIPTION	QTY
1	Top Hinge	(1)
2	Hinge Pin	(1)
3	Bottom Hinge	(1)
4	Hinge Pinde Nylon	(1)
5	Hinge Washer External	(1)
6	Hinge Washer Internal	(1)
7	Hinge Nut 5/16"	(1)
8	Box cam Nylon	(1)
9	Indicator Side Latch Outside	(1)
10	Indicator Silde Latch Inside	(1)
11	Coat Hook & Bumper	(1)
12	Step Bolt 1-1/4"	(4)
13	Barrel Nut 5/6"	(4)
14	Screw #10 x 5/8"	(6)
15	Step Balt 1"	(2)
16	Keeper	(1)
17	Door Pull Inside	(1)
18	Door Pull Outside	(1)
19	Indicator Drive Pin	(1)
20	Outswing Bumper	(1)
21	Step Balt 1-1/2"	(2)
22	Plaster	(1)
23	Door	(1)

Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
Fax: (409) 840-3543
info@ameraproducts.com





	Headrail	Hardware Kit (P/N 40-8448100G) Includes:	
P	ART ID.	DESCRIPTION	QTY
1		Headrail Satin "F" Zamac Bracket	(2)
2	<b>a</b>	Headrail Cap Satin Zamac	(1)
3	<del></del>	Vandal Resistant S/S 2 1/2" S.M.S	(2)
4	<b>=</b>	Plastic Shield	(2)
5	8	VandalResistant S/S 5/8" S.M.S	(4)




Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-5542
info@ameraproducts.com




#### URINAL SCREEN ASSEMBLY

- Before proceeding,confirm that backing of wall is adequate to support and secure mounting of urinal screens. Check dwgs for layout.
- B. Insert anchoring devices in walls and secure wall brackets with 2 1/2" s.m.s.
- C. Place urinal screen on a support, 12" above the floor.
- D. Set U/S into wall brackets and fasten urinal screen at this time, using 5/8" fasteners.

	Urinal	Screen Hardware Kit (P/N 40-8511281G) Ir CHROME PLATED ZAMAC	cludes:
	Urinal	Screen Hardware Kit (P/N 40-8261281G) Ir STAINLESS STEEL	cludes:
P	ART ID.	DESCRIPTION	QTY
1	<u> </u>	Two Ear Wall U/S Bracket	(2)
2	-	Vandal Resistant 2 1/2" S.M.S	(4)
3		Plastic Shields	(4)
4	(hann-	Vandal Resistant 5/8" S.M.S	(8)





Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-5542
info@ameraproducts.com




FIGURE 1



#### STEP 1 LAYOUT


NOTE: FLOOR MUST BE CONCRETE.

- A. Review the layout drawngs and package lists that have accompanied this job.
- B. Before proceeding, confirm that backing of walls and floor is adequate to support secure mounting of the toilet compartment units.
- C. Establish and mark pilaster center line from back wall.
- D. Establish and mark panel center lines for wall brackets.
- E. Establish pilaster floor fastener locations from side wall according to shop drawings. (Note floor fasteners are located 1" from edge of pilaster.)
- F. Mark wall bracket holes using brackets as templates.




# STEP 2 WALL BRACKETS AND FLOOR BRACKETS

- A. Drill holes for wall brackets of 1/4" and floor fastenings of 3/8" for fastening devices supplied.
- B. Insert anchoring devices in walls and secure wall brackets.
- C. Install wedge anchor with shoe clip washer and nut into concrete floor (min. 2 1/2") and tighten.



# STEP 3 POSITION PANEL

- A. Place panel on a support, 12" above the floor.
- B. Set it into wall brackets,but do not fasten panel at this time.




Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-3543
info@ameraproducts.com






# STEP 4 PILASTER PREPARATION

- A. Align U-brackets in position on rear of pilasters. Refer to layout drawings for placement.
- B. Fasten U-brackets to pilaster with sheet metal screws pre-drilling with 1/8" bit.
- C. Pilasters at wall do not require U-brackets,but should be prepared for wall (and floor fastening) as required by compartment layout.




#### STEP 5 INSTALL PILASTERS

- A. On each wedge anchor thread place one shoe clip and 3/8" support nut down to approximately 1" up from floor level and place round washer over each anchor.
- B. Inspect shoe for bowing. Squeeze edges and center of shoe to ensure shoe will not bow away from pilaster faces. Slide stainless steel shoe carefully over mounting end of pilaster and leave approximately 5" above end.
- C. Position pilaster on anchors and secure lightly with flat washers and 3/8" locking nuts.



# STEP 6 SECURING PILASTERS /PANELS

- A. Level each pilaster by adjusting both support nuts to desired position.
- B. Plumb each pilaster and fasten the pilaster to panel with "u" brackets using through bolts or sheet metal screws.
- C. Establish door openings by setting pilaster mounting channel to desired position on anchor.
- D. Tighten locking nuts on top of pilaster mounting channel.
- E. Slide stainless steel shoe down to floor level, firmly engaging shoe clips.
- F. Remove panel support device.



Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-3543
info@ameraproducts.com

FIGURE 6





# FLOOR ANCHORED PANEL TO PILASTER/WALL TWO EAR ASSEMBLY


Fasten pilaster to panel using sheet metal screws(Refer to steps 4 & 6)

Pre-drill for screws with 1/8" bit.

Pilasters must be both plumb and level. To assist in leveling, headrail may be lightly positioned across adjacent pilasters(do not fasten at this time)

Remove support device.

	Panel H	lardware Kit (P/N 40-8515020G) Includes:	
9		CHROME PLATED ZAMAC	
	Panel H	lardware Kit (P/N 40-8265021G) Includes:	
		STAINLESS STEEL	
PA	ART ID.	DESCRIPTION	QTY
1	Щ	Two Ear Bracket	(2)
2	Ш	"U" Bracket	(2)
3	<b></b>	VandalResistant C/P 2 1/2" S.M.S	(4)
4		Plastic Shields	(4)
5		Vandal Resistant C/P 5/8" S.M.S	(12)






# FLOOR ANCHORED PANEL TO PILASTER/WALL ONE EAR ASSEMBLY

Pilasters must be both plumb and level.

- A. Plumb pilaster and fasten pilaster to panel using through bolts or sheet metal screws and "U" brackets.
- B. Establish bottom door openings by adjusting pilaster and tightening screws.(Refer to step 4 & 6)
- C. Remove support device.

	Par	nel Hardware Kit (P/N 40-8515010G) Includes: CHROME PLATED ZAMAC	
	Pane	el Hardware Kit (P/N 40-8265011G) Includes: STAINLESS STEEL	
PA	ART ID.	DESCRIPTION	QTY
1	Щ	One Ear Bracket	(2)
2	Ш	"U" Bracket	(2)
3	9	Vandal Resistant 2 1/2" S.M.S	(4)
4		Plastic Shields	(4)
5	-	Vandal Resistant 5/8" S.M.S	(12)









### FLOOR ANCHORED PILASTER/WALL ASSEMBLY


Pilasters must be both plumb and level.

Pre-drill for screws with 1/8" bit.

	Pilaste	er/Wall Hardware Kit (P/N 40-8515210G) Inclu CHROME PLATED ZAMAC	des:
	Pilaste	er/Wall Hardware Kit (P/N 40-8265211G) Inclu STAINLESS STEEL	des:
P	ART ID.	DESCRIPTION	QTY
1		One Ear Wall Bracket	(2)
2	-	Vandal Resistant 2 1/2" S.M.S	(4)
3		Plastic Shields	(4)
4	-	Vandal Resistant 5/8" S.M.S	(8)







NOTE: Replace Vandal Resistant 2 1/2" SMS With Vandal Resistant 5/8" SMS To Fasten Pilaster To Panel Instead Of Wall.

FIGURE B






#### FLOOR ANCHORED PILASTER/PANEL ALCOVE ASSEMBLY

Note:

Replace P/N#40-8515010G with P/N#40-8515020G for two ear locations.

	Pane	el Hardware Kit (P/N 40-8515010G) Inc CHROME PLATED ZAMAC	cludes:
	Pane	el Hardware Kit (P/N 40-8265011G) Ind STAINLESS STEEL	cludes:
PAF	RT ID.	DESCRIPTION	QTY
1	Ц	One Ear Bracket	(2)
2	Ш	"U" Bracket	(2)
3		Vandal Resistant 2 1/2" S.M.S	(4)
4		Plastic Shields	(4)
5	<b> </b>	Vandal Resistant 5/8" S.M.S	(12



Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
rax: (409) 840-5542
info@ameraproducts.com



FIGURE 1

FIGURE 3




#### STEP 1 LAYOUT CEILING HUNG

- A. Review the layout drawings and package lists that have accompanied this job.
- B. Top of the finished ceiling and bottom edge of structural support should not exceed 1".
- C. Before proceeding, confirm that backing of wall and ceiling support is adequate to secure mounting of toilet compartment
- D. Confirm correct location and condition of threaded ceiling rods. These should project 2" to 2-1/2" below finished ceiling.
- E. Establish and mark pilaster and panel center lines in relation to ceiling rod locations and drawings. Bolts will be located 1" from edge of pilaster
- F. Mark wall bracket holes using brackets as templates.

# 48"


#### STEP 2 WALL BRACKETS

- A. Drill holes for wall brackets of appropriate size for particular fastening devices supplied.
   Typically 1/4" drill bits can be used throughout.
- B. Insert anchoring devices in walls and secure wall brackets.
- C. Pilaster at wall should be prepared for wall and ceiling fastening as required by compartment layout.



# STEP 3 POSITION PANEL

- A. Place panel on a support, 12" above the floor.
- B. Set it into wall brackets,but do not fasten panel at this time as it may need to be raised or lowered to sit flush with pilaster bottoms.




Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
rax: (407) 840-3543
info@ameraproducts.com





## STEP 4 PILASTER PREPARATION


- A. Align U-brackets in position on rear of pilasters. Refer to layout drawings.
- B. Fasten U-brackets to pilaster with sheet metal screws pre-drilling with 1/8" bit.
- C. Pilasters at wall do not require U-brackets.



# STEP 5 INSTALL PILASTERS

NOTE: STRUCTURAL STEEL BY OTHERS


- A. Slide stainless steel shoe carefully over mounting end of pilaster and leave approximately 5" above bottom end.
- B. Thread support nuts and mounting washers over threaded rods to support pilaster mounting bar.
- C. Position pilaster and mounting channel on threaded rods and attach lightly with square flat washer, lockwasher and locking nut.



CEILING BOLT DETAIL

# STEP 6 SECURING PILASTERS TO PANELS

- A. Level each pilaster by adjusting both support nuts to desired position.
- B. Plumb each pilaster and fasten the pilaster to panel using through bolts or sheet metal screws.
- C. Establish door openings by setting pilaster mounting channel to desired position on stud.
- D. Tighten locking nuts on top of pilaster mounting channel.
- E. Slide stainless steel shoe up to ceiling level, firmly engaging shoe clips.
- F. Fasten panel to wall brackets using through bolts.
- G. Remove panel support device.



Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-3543
info@ameraproducts.com






# CEILING HUNG PANEL TO PILASTER/WALL TWO EAR ASSEMBLY

Fasten pilaster to panel using through bolts with barrel nuts or sheet metal screws.

Pilasters must be both plumb and level. (do not fasten at this time)

Establish bottom door openings by adjusting pilaster and tightening screws.(Refer to step 6)

D.			
	Panel F	lardware Kit (P/N 40-8515020G) Includes: CHROME PLATED ZAMAC	
	Panel H	lardware Kit (P/N 40-8265021G) Includes: STAINLESS STEEL	
P/	ART ID.	DESCRIPTION	QTY
1		Two Ear Bracket	(2)
2	Ш	"U" Bracket	(2)
3	<b></b>	Vandal Resistant 2 1/2" S.M.S	(4)
4		Plastic Shields	(4)
5	-	Vandal Resistant 5/8" S.M.S	(12)








# CEILING HUNG PANEL TO PILASTER/WALL ONE EAR ASSEMBLY

Fasten pilaster to panel using sheet metal screws.

Pilasters must be both plumb and level. (do not fasten at this time)

Establish bottom door openings by adjusting pilaster and tightening screws.(Refer to step 6)

	Pa	nel Hardware Kit (P/N 40-8515010G) Includes:	
	Do	CHROME PLATED ZAMAC	
	Pa	nel Hardware Kit (P/N 40-8265011G) Includes: STAINLESS STEEL	
P	ART ID.	DESCRIPTION	QTY
1	Щ	One Ear Bracket	(2)
2	Ш	"U" Bracket	(2)
3	-	Vandal Resistant 2 1/2" S.M.S	(4)
4		Plastic Shields	(4)
5	-	Vandal Resistant 5/8" S.M.S	(12










#### CEILING HUNG PILASTER/WALL ASSEMBLY

Pilasters must be both plumb and level.

	Pilaste	er/Wall Hardware Kit (P/N 40-8515210G) Includ CHROME PLATED ZAMAC	les:	
	Pilaste	er/Wall Hardware Kit (P/N 40-8265211G) Includ STAINLESS STEEL	les:	
P.	PART ID. DESCRIPTION QT			
1	Щ	One Ear Wall Bracket	(2)	
2	<del></del>	Vandal Resistant 2 1/2" S.M.S	(4)	
3		Plastic Shields	(4)	
4	-	Vandal Resistant 5/8" S.M.S	(8)	







Replace Vandal Resistantt 2 1/2" SMS With Vandal Resistant 5/8"SMS To Fasten Pilaster To Panel.

Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
Fax: (409) 840-3542
info@ameraproducts.com






# CEILING HUNG PILASTER/PANEL ALCOVE ASSEMBLY

#### Note:

Replace P/N#40-8515010G with P/N#40-8515020G for two ear locations.

		515010G) Includes: PLATED ZAMAC	(P/N 40-8265011G) Includes: STAINLESS STEEL
PA	ART ID.	DESCR	RIPTION QT
1	Ц	One Ear Bracket	G
2	Ш	*U" Bracket	G
3	-	Vandal Resistant 2 1/2"	S.M.S (4
4	<b>=</b>	Plastic Shields	(4
5	-	Vandal Resistant 5/8" S	.M.S (*



Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
rax: (409) 840-3543
info@ameraproducts.com



#### STEP 1 LAYOUT FLOOR AND CEILING ANCHORED

- A. Review the layout drawings and package lists that have accompanied this job.
- B. Before proceeding, confirm that backing of walls and floor is adequate to support secure mounting of the toilet compartment units.
- C. Establish and mark pilaster center line from back wall.
- D. Establish and mark panel center lines for wall brackets.
- E. Establish pilaster floor and ceiling fastener locations from side wall according to shop drawings. (Note fasteners are located roughly 1" from lockstrip edge of pilaster.)
- F. Mark wall bracket holes using brackets as templates.

# STEP 2 WALL BRACKETS AND FLOOR BRACKETS

- A. Drill holes for wall brackets and floor fastenings of appropriate size for particular fastening devices supplied. Typically 1/4" drill bits can be used throughout.
- B. Insert anchoring devices in walls and secure wall brackets.
- C. Insert anchors and ceiling bolts.
   Position shoe clips and "L" brackets.
   Details in STEP 5.

(Note ceiling "L" brackets engraved for identification)

#### STEP 3 POSITION PANEL

- A. Place panel on a support, 12" above the floor.
- B. Set it into wall brackets,but do not fasten panel at this time.

#### FIGURE 1




FIGURE 2





FIGURE 3




Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
rax: (409) 840-3543
info@ameraproducts.com



# STEP 4 PILASTER PREPARATION

- A. Align U-brackets in position on rear of pilasters. Refer to layout drawings.
- B. Fasten U-brackets to pilaster with sheet metal screws.
- C. Pilasters at wall do not require U-brackets,but should be prepared for wall (floor & ceiling fastening) as required by compartment layout.




#### STEP 5 INSTALL PILASTERS

#### NOTE

Structural steel should be 2 1/2" inches MAX from the bottom of the finished ceiling.


A. Slide stainless steel shoes carefully over mounting ends of pilaster and leave approximately 5" space from end.

B. Place pilaster between "L" brackets adjust jack leveling bolt and fasten loosely with screws at predrilled locations at each side.



#### STEP 6 SECURING PILASTERS TO PANELS

- A. Plumb each pilaster by adjusting self tapping screws at top & bottom to desired position & tighten.
- B. Fasten the pilaster to panel using sheet metal screws.
- C. Establish door openings by setting pilaster to desired position. (Refer to layout drawings)
- D. Slide stainless steel shoe up to ceiling level & down to floor level, firmly engaging shoe clips.
- E. Fasten panel to wall brackets using sheet metal screws.
- F. Remove panel support device.



CADMIUM PLATED JACK BOLT

MOUNTING FOOT

"L" BRACKETS

SELF TAPPING SCREW

SHOE CLIP

Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
rax: (409) 840-5543
info@ameraproducts.com




# PANEL TO PILASTER/WALL TWO EAR ASSEMBLY

Fasten pilaster to panel using sheet metal screws.

Pilasters must be both plumb and level. (do not fasten at this time)

Establish bottom door openings by adjusting pilaster and tightening screws.(Refer to step 6)

	Panel H	lardware Kit (P/N 40-8515020G) Includes:	
	Panel F	CHROME PLATED ZAMAC  lardware Kit (P/N 40-8265021G) Includes:  STAINLESS STEEL	
P/	ART ID.	DESCRIPTION	QTY
1		Two Ear Bracket	(2)
2	Ш	"U" Bracket	(2)
3	<b>I</b>	Vandal Resistant C/P 2 1/2" S.M.S	(4)
4		Plastic Shields	(4)
5	-	Vandal Resistant C/P 5/8" S.M.S	(12)



Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-3542
info@ameraproducts.com




# FLOOR AND CEILING ANCHORED PANEL TO PILASTER/WALL ONE EAR ASSEMBLY

Fasten pilaster to panel using sheet metal screws.

Pilasters must be both plumb and level. (do not fasten at this time)

Establish bottom door openings by adjusting pilaster and tightening screws.(Refer to step 6)

	Pa	nel Hardware Kit (P/N 40-8515010G) Inc CHROME PLATED ZAMAC	udes:
	Pa	nel Hardware Kit (P/N 40-8265011G) Inc STAINLESS STEEL	ludes:
P/	ART ID.	DESCRIPTION	QTY
1	Ц	One Ear Bracket	(2)
2	Ш	"U" Bracket	(2)
3	-	Vandal Resistant 2 1/2" S.M.S	(4)
4		Plastic Shields	(4)
5	-	Vandal Resistant 5/8" S.M.S	(12)



Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
Fax: (409) 840-3543
info@ameraproducts.com




# FLOOR AND CEILING ANCHORED PILASTER/WALL ASSEMBLY


Fasten pilaster to panel using sheet metal screws.

Pilasters must be both plumb and level. (do not fasten at this time)

Establish bottom door openings by adjusting pilaster and tightening screws.(Refer to step 6)


	Pilaster/Wall Hardware Kit (P/N 40-8515210G) Includes: CHROME PLATED ZAMAC				
	Pilaster/	Wall Hardware Kit (P/N 40-8265211G) Includ STAINLESS STEEL	les:		
P	PART ID. DESCRIPTION QT				
1	Щ	One Ear Wall Bracket	(2)		
2	-	Vandal Resistant 2 1/2" S.M.S	(4)		
3		Plastic Shields	(4)		
4	-	Vandal Resistant 5/8" S.M.S	(8)		





Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
rax: (409) 840-3545
info@ameraproducts.com






Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
rax: (409) 840-5545
info@ameraproducts.com



FLOOR AND CEILING ANCHORED PILASTER/PANEL/PILASTER INLINE ASSEMBLY

P/	ART ID.	DESCRIPTION	QTY
1	•	Alcove Clips	(12)
2	<b>-</b>	Vandal Resistant Step Bolts 1" Long	(12)
3	<b>#</b> =	Vandal Resistant Barrel Nut	(12)
4	_	Vandal Resistant 5/8* S.M.S	(12)




NOTE: Replace Vandal Resistant 2 1/2" SMS With Vandal Resistant 5/8" SMS To Fasten Pilaster To Panel.

Distributed by www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-5543
info@ameraproducts.com








Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
rax: (409) 840-5545
info@ameraproducts.com







Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
rax: (409) 840-3542
info@ameraproducts.com






OPTIONAL FULL HEIGHT PILASTER/WALL ASSEMBLY

	Pila	ster/Wall Hardware Kit (P/N 8446210) Include ALUMINUM FULL HEIGHT	<b>18</b> :
P	ART ID.	DESCRIPTION	QTY
1	Щ	5441840 One Ear Wall Bracket	(2)
2		3910700 Theft Resistant C/P Step Bolts 1 1/4" Long	(8)
3	<b>(</b> =	3910890 Theft Resistant C/P Barrel Nut	(6)
4	-	3910450 TheftResistant C/P #14 x 2 1/2" S.M.S	(12)
5		3080000 Plastic Shields	(12)
6	-	3914120 Theft Resistant C/P #14 x 5/8" S.M.S	(8)

ALSO AVAILABLE IN STAINLESS STEEL P/N 6266210



Distributed by
www.AmeraProducts.com
Phone: (800) 608-6548
Fax: (409) 840-3541
info@ameraproducts.com







#### OPTIONAL FÜLL HEIGHT URINAL SCREEN ASSEMBLY

- A. Before proceeding, confirm that backing of wall is adequate to support and secure mounting of urinal screens.
- B. Insert anchoring devices in walls and secure wall brackets.
- C. Place urinal screen on a support, 12" above the floor.
- D. Set it into wall bracket and fasten urinal screen at this time.

	Urinal Sc	reen Hardware Kit (P/N 8449000) Includes ALUMINUM FULL HEIGHT	
P	ART ID.	DESCRIPTION	QTY
1	##	5449000 38" Long Two Ear Wall U/S Bracket	(1)
2	-	3910450 Theft Resistant C/P #14 x 2 1/2" S.M.S	(8)
3		3080000 Plastic Shields	(8)
4	<b>(===</b>	3910600 Theft Resistant C/P Step Bolts 1" Long	(4)
5		3910690 Theft Resistant C/P Barrel Nut	(4)

ALSO AVAILABLE IN STAINLESS STEEL P/N 8269000





Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
rax: (409) 840-3543
info@ameraproducts.com



# CARE AND MAINTENANCE OF TOILET PARTITIONS

In order to provide toilet partitions with the care and maintenance, the following instructions must be followed.

- A. All surfaces must be kept clean with water and mild soap solution only.
  - B. In high humidity areas, the rooms must be properly ventilated.
- C. "Hosing down" or wet washing of these units may cause water absorption and damage
- D. For maximum protection, periodic application of any standard furniture wax will be beneficial.

E. In order to provide toilet partitions with the proper care and maintenance, the above instructions must be followed.

#### WARNING

Under no circumstances should the components be subjected to:

\* Abrasive powders or pads \*Water closet cleaners

\*Ceramic tile cleaners

\*Solutions containing more than 1% by volume of ammonia

\*Solutions containing acids or lye

\*Solutions containing enzymes

Attention to work progress during new construction or renovation is important.

Other trades and cleaning services may use agents for ceramics and tiles that will damage these

components.

Distributed by
www.AmeraProducts.com
Phone: (800) 608-6568
Fax: (409) 840-3542
info@ameraproducts.com