

# Diaper-Depot Installation Template

*Plantilla de Montaje*

## For Use With Diaper-Depot Installation Instructions ONLY

1. Locate the studs in your walls to determine if they are 16 inches or 24 inches apart.  
*Ubique los montantes de las paredes para determinar que juego de agujeros de montaje usará, a 16 pulg. o 24 pulg. en el centro.*
2. Attach this Installation Template to the wall. If your studs are 16 inches apart, line up the centers of the squares on this template with your wall studs. If your studs are 24 inches apart, line up the centers of the circles on this template with your wall studs.  
*Cuelgue la Plantilla de Montaje incluido en el lugar deseado de la pared, para que los agujeros de montaje de la plantilla estén en línea con los montantes de la pared.*
3. Make sure the bottom marked edge of this template is 25" from the floor. This will assure that your Diaper-Depot will meet ADA guidelines, where applicable.  
*Asegúrese que la plantilla este a la altura correcta, para que la altura A.F.F. indicada este a la distancia apropiada desde el suelo. Esto ayuda a que la unidad se instale en cumplimiento con las disposiciones del ADA.*
4. Follow remaining instructions on your Diaper-Depot Installation Instructions, included with your Diaper-Depot Changing Station.

Distributed by  
[www.Ameraproducts.com](http://www.Ameraproducts.com)

Phone: (800) 608-6568

Fax: (409) 840-5545

[info@ameraproducts.com](mailto:info@ameraproducts.com)